

# LED Run Brake Turn Lights for Harley Ultra Limited

VST-010102-006



## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

## IMPORTANT

This headlight is exclusively designed for your motorbike. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

### 1. Product and Accessories



2. First, remove the saddlebags on both sides of the motorcycle, find the screw positions marked on the picture, and unscrew the nuts (the screws do not need to be removed). Then fix the tail light bracket on the screw as shown in the figure, and then screw back the nuts. (same operation on the other side), as shown in the picture:



# LED Run Brake Turn Lights for Harley Ultra Limited

VST-010102-006



3. Pass the tail light harness through the hole on the mounting bracket, and then use the screws provided in the package to fix it from the back of the mounting bracket (be careful not to tighten the screws too tightly at one time. Tighten the two screws after they are all fixed). The taillight on the other side operate in the same way, as shown in the picture:



# LED Run Brake Turn Lights for Harley Ultra Limited

VST-010102-006



4. Open the motorcycle seat cushion, find the original taillight harness near the motorcycle trunk, pull out the interface as shown in the figure, and reconnect the adapter cable provided in the product package with the original taillight harness. Then pull the extension cable to the taillight and connect it with the taillight harness. Finally hide the exposed wiring harness. After the taillights are installed, put the saddlebags on both sides back to their original positions.

**Note:** When the extension cable is connected to the tail light, connect one of them first, then start the motorcycle, turn on the turn signal switch, and check whether the turn signal of the tail light is on. If not, replace the other extension wire and reconnect it.



5. Installation finished.

