LED Front Lower Fork Leg Covers for Harley Road Glide

VST-010102-007



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This LED front lower fork leg covers is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Products and accessories





2. Unscrew the screw on the motorcycle's front brake lever and remove the its front brake reflector. Install the product according to the left and right directions, and then fix it with the screws provided with the product, as shown in the picture:





LED Front Lower Fork Leg Covers for Harley Road Glide

VST-010102-007





3.Remove the fog light bracket of the motorcycle, disconnect the wiring harness plug-in, and pull the wiring harness of this product to the fog light along the direction of the whole vehicle wiring harness. Connect one end of the wiring harness with steering function to the fog light wiring harness plug-in, and the other end to the vehicle wiring harness plug-in, and finally install the fog light bracket. (The installation steps on the other side are the same as above), as shown in the picture:







4.Remove the motorcycle headlights and disconnect the wiring harness. Connect the adapter cable provided in the product package with one end to the headlight and the other end to the original car wiring harness; connect the two separate sub-wires to the main wiring harness plug-ins for the brake decorative lights on both sides. Start the motorcycle and turn on the turn signal switch to check if the lamps are functioning properly. Finally put the headlight back in place, as shown in the picture:

LED Front Lower Fork Leg Covers for Harley Road Glide

VST-010102-007









5. Installation finished.

