

Handguards Protector Kit for Pan America 1250

VST-010103-013



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This handguards protector kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

Kit Contents



INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Fix the handguard bracket on the vehicle body with screws (The bracket is divided into left and right sides, and then installed after differentiating in advance).



Handguards Protector Kit for Pan America 1250

VST-010103-013



3. First clamp the smoked handguard into the black handguard, then insert one end with the U-notch into the rear of the handguard and fix the other end on the bracket with screws (Install the handguard on the other side by the same steps).



4. Installation complete.

