

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

These saddle shield heat deflectors are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Unscrew the screws on both sides under the original car seat cushion. Shows as the picture:



2. First, distinguish whether the product is left or right. Then, peel off the release film on the back of the product. Lastly, use the unscrewed original vehicle screws to pass through the mounting holes of the heat shield and fix it back to the car (The other side is installed in the same way). Shows as the picture:



Saddle Shield Heat Deflector for Harley Sportster VST-010103-034





3. Finish installation.



