

Intake Vent Accent Trim for Harley Road Glide

VST-010103-041



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This intake vent accent trim is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Products Display



2. Wipe the original intake vent accent surface clean, then uncover the adhesive film on the back of the intake vent accent trim strip and paste it (press hard to make it fit more tightly). As the picture shows:



3. Installation finished.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.