

Front Brush Guard for Harley-Davidson RA1250

VST-010106-001



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This FRONT BRUSH GUARD KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

REF	QTY	PART DESCRIPTION
1	1	Side bumper L
2	1	Side bumper R
3	6	8*25 flange screw

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Products and accessories.



Front Brush Guard for Harley-Davidson RA1250

VST-010106-001



3. Fix the Side bumper with six 8*25 flange screws into the 6 threaded holes as shown.

